


---

# Wheel Balancer Manual

2025





## **Warning**

- This manual is a necessary part of the product. Please read carefully.
- Keep the manual for later use when maintaining the machine.
- This machine can only be used for the designated purposes. Never use it for any other purpose.
- The manufacturer is not responsible for the damage incurred by improper use or use other than the intended purpose.

## **Precaution**

- The equipment can only be operated by qualified personnel with special training. Modification to any components or parts, or use the machine for other purpose without either obtaining the agreement from the producer, or observing the requirement of the instructions may lead to direct or indirect damage to the equipment.
  - ★ The equipment should be installed on the stable ground, not wooden pallet, otherwise not accurate.
- Keep the back panel 0.6M away from the wall for good ventilation. Enough room should be left on both sides for convenient operation.
- Do not put the equipment a place with high temperature or moisture, or near the heating system, water tap, air-humidifier or chimney.
  - Avoid lots of dust, ammonia, alcohol, thinner or spraying binder.
  - People who are no operating the machines should be kept away when it is used.
  - Use appropriate equipment and tools, protective and safety equipment, including eyeglasses, earplugs and working boots.
- Pay special attention to the marks on the machine.
- Do not touch or approach the moving parts by hand during operating.
- Do not remove the safety device or keep it from working properly.

---

## Contents

|                                              |    |
|----------------------------------------------|----|
| 1. General-----                              | 1  |
| 2. Machine assembly-----                     | 1  |
| 3. Controls and components-----              | 3  |
| 4. Indication and use of wheel balancer----- | 6  |
| 5. Self-calibration of wheel balancer -----  | 8  |
| 6. Errors-----                               | 9  |
| 7. Self- diagnoses-----                      | 10 |
| 8. Setting machine-----                      | 10 |
| 9. Installation of motorcycle adaptor-----   | 11 |
| 10.OPT function-----                         | 12 |

# 1. General

## 1.1. Technical data:

- Max wheel weight: 65kg
- Power: 0.2kw
- Power supply: 220v;230v;240v;110v;50hz;60hz
- Balancing accuracy:  $\pm 1g$
- 6 balancing modes: DYN, ALU1, ALU2, ALU3 , ST
- Balancing speed: 200r/min
- Cycle time: 8s
- Rim diameter: 10 " ~ 24 " (256mm~610mm)
- Sound pressure level during work cycle: <70db

## 1.2. Features:

- Balance car wheel or motorcycle wheel according to different mode setting.
- Motorcycle adaptor is default under motorcycle mode.
- Statistic and dynamic balancing, ALU-programs for alloy rims or special shaped
- Self diagnoses, easy to find the problem
- Apply to steel and aluminum alloy rim

## 1.3. Working environment:


- Temperature: 5~50°C
- Height:  $\leq 4000m$

# 2. Machine assembly

## 2.1. Unpack


Unpack the carton, check if missing any spare parts.

| No. | Item               | Qty |
|-----|--------------------|-----|
| 1   | Width gauge        | 1   |
| 2   | Conic No.1         | 1   |
|     | Conic No.2         | 1   |
|     | Conic No.3         | 1   |
|     | Conic No.4         | 1   |
| 3   | Quick release nut  | 1   |
| 4   | Thread hub         | 1   |
| 5   | Bowl for quick nut | 1   |
| 6   | Pad for bowl       | 1   |
| 7   | Balancing hammer   | 1   |
| 8   | 100g weight        | 1   |
| 9   | Allen wrench       | 1   |



## 2.2. Install


- The equipment should be installed on the stable ground, not wooden pallet, otherwise not accurate.
- Keep the back panel 0.6M away from the wall for good ventilation. Enough room should be left on both sides for convenient operation.



2.3. Fix balancer to floor with screws on the bottom.

## 2.4. Install adaptor

The wheel balancer is supplied complete with cone type adaptor for fastening wheel with central bore. (see below picture)




## 2.5. Install wheel

Clean wheel, take off counterweights, check pressure of wheel.

Choose the way of installation according to the type of wheel.



Main shaft—wheel—  
suitable cone( small head towards inside)—quick handle nut




Main shaft—suitable cone(big head towards inside)  
—wheel—quick handle nut


**Attention:** May add a wheel, and hold the wheel to help install the thread hub. When installing or taking off wheel, do not let wheel move on the shaft, to avoid scratching shaft.

### 3. Controls and components

| No. | Item                 | Standard/Optional |
|-----|----------------------|-------------------|
| A   | Switch               | S                 |
| B   | Head with tools tray | S                 |
| C   | Gauge head           | S                 |
| D   | Main shaft           | S                 |
| E   | Laser                | S                 |
| F   | Safe guard           | S                 |
| G   | Keyboard             | S                 |



## Keyboard (G)



1.inside unbalance value digital display


2.inside unbalance position display

3.outside unbalance value digital display


4.outside unbalance position display

5.balancing mode chosen.


### Six balancing modes

| Icon                                                                                | Balancing mode   | Operation                                                                                                                                                                                 | Add weights                                                                    |
|-------------------------------------------------------------------------------------|------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------|
|  | Standard/Default | <ol style="list-style-type: none"> <li>1. Turn on machine</li> <li>2. Input a,b,d value</li> <li>3. Start spin, after spin stop</li> </ol>                                                | Clip on weights on both sides of rim edge                                      |
|  | Static mode      | <ol style="list-style-type: none"> <li>1. Turn on machine</li> <li>2. Input a,b,d value</li> <li>3. Start spin, after spin stop</li> <li>3. Press F button</li> </ol>                     | Add adhesive weight                                                            |
|  | ALU1             | <ol style="list-style-type: none"> <li>1. Turn on machine</li> <li>2. Input a,b,d value</li> <li>3. Press ALU button, indicator lit up</li> <li>4. Start spin, after spin stop</li> </ol> | Add adhesive weights on the rim shoulder both sides                            |
|  | ALU2             | <ol style="list-style-type: none"> <li>1. Turn on machine</li> <li>2. Input a,b,d value</li> <li>3. Press ALU button, indicator lit up</li> <li>4. Start spin, after spin stop</li> </ol> | Add adhesive weights on the rim shoulder both sides                            |
|  | ALU3             | <ol style="list-style-type: none"> <li>1. Turn on machine</li> <li>2. Input a,b,d value</li> <li>3. Press ALU button, indicator lit up</li> <li>4. Start spin, after spin stop</li> </ol> | Clip on weight on inside rim edge, add adhesive weight on outside rim shoulder |

\*Pay attention to the unbalanced position to add weight according to the settings\*

| LAS=OFF       |                                                                                     |               | LAS=ON        |                                                                                       |               |
|---------------|-------------------------------------------------------------------------------------|---------------|---------------|---------------------------------------------------------------------------------------|---------------|
| inside        | Balancing mode                                                                      | outside       | inside        | Balancing mode                                                                        | outside       |
| 12<br>o'clock |    | 12<br>o'clock | 12<br>o'clock |    | 12<br>o'clock |
| 12<br>o'clock |    | 12<br>o'clock | 12<br>o'clock |    | 12<br>o'clock |
| 12<br>o'clock |    | 12<br>o'clock | 6H            |    | 12<br>o'clock |
| 12<br>o'clock |    | 12<br>o'clock | 6H            |    | 6H            |
| 12<br>o'clock |  | 12<br>o'clock | 12<br>o'clock |  | 6H            |

#### Key board (H)

| Icon                                                                                | Function         | Icon                                                                                | Function                              |
|-------------------------------------------------------------------------------------|------------------|-------------------------------------------------------------------------------------|---------------------------------------|
|  | Set distance     |  | Optimization of unbalance             |
|  | Set rim width    |  | Selection of “ALU” modes              |
|  | Set rim diameter |  | Static mode                           |
|  | Recalculation    |  | Unbalance display pitch and threshold |
|  | Start            |  | Stop/Cancel                           |

## 4. Indication and use of wheel balancer


### 4.1. DYN (Standard/Default) mode

4.1.1. Clean wheel, take off counterweights, check pressure of wheel. Choose the way of installation according to the type of wheel.



Main shaft-wheel—

suitable cone( small head towards inside)—quick handle nut




Main shaft-suitable cone(big head towards inside)

—wheel—quick handle nut

**Attention: May add a wheel, and hold the wheel to help install the thread hub. When installing or taking off wheel, do not let wheel move on the shaft, to avoid scratching shaft.**

4.1.2. Turn on machine

4.1.3. Input a b d value



- Move gauge to touch edge of rim (**Fig.1**), read the value of distance, press **a+** and **a-** to change, set “a” value.
- Use width gauge to read the value of width (**Fig. 2**), press **b+** and **b-** to change, set “b” value.
- Read the value of diameter (marked on the wheel), press **d+** and **d-** set “d” value.




Fig.1



Fig.2

4.1.4. Put down the guard to perform a measuring spin.

4.1.5. In a few seconds the wheel is brought to operating speed and begin measuring unbalance, the unbalance values

remain on instruments 1 and 3 when the wheel stopped. Press  may check the real unbalance value under threshold.

4.1.6. Anticlockwise moving wheel slowly, the displays with right LED's lit up full indicate the correct angular position where to mount the counterweights (12 o'clock position) outside, as **Fig.3**, clip the counterweight.




Fig. 3

4.1.7. Anticlockwise moving wheel slowly, the displays with left LED's lit up full indicate the correct angular position where to mount the counterweights (12 o'clock position) inside, as **Fig.4**, clip the counterweight.




Fig. 4

4.1.8. After finishing clipping the counterweights, put down the guard to perform balancing spin again, if comes out 00 00, means balancing succeed. (**Fig.5**)



Fig. 5

## 4.2. ALU-2 mode (ALU-1, ALU3 same operation, only the position to add weights different)

4.2.1. Set "a" "d" "b" values

4.2.2. Press  until ALU2 indicator lit up

4.2.3. Put down the guard to perform a measuring spin.

4.2.4. In a few seconds the wheel is brought to operating speed and begin measuring unbalance, the unbalance values remain on instruments 1 and 3 when the wheel stopped. Press  may check the real unbalance value under threshold.

4.2.5. Anticlockwise moving wheel slowly, the displays with right LED's lit up full indicate the correct angular position where to mount the counterweights, **(LAS=OFF )12 o'clock , (LAS=ON )6 o'clock position** outside, as **Fig.6**, add the counterweight.



Fig. 6

4.2.6. Anticlockwise moving wheel slowly, the displays with left LED's lit up full indicate the correct angular position where to mount the counterweights, **(LAS=OFF )12 o'clock , (LAS=ON )6 o'clock position** inside, as **Fig.7**, add the counterweight.



Fig. 7

4.2.7. After finishing mounting the counterweights, put down the guard to perform balancing spin again, if comes out 00 00, means balancing succeed. (Fig.8)



Fig. 8

5.Self-calibration of wheel balancer

Turn on balancer, install a medium size wheel (13"-16")which can use clip-on weight, set "a b d" value, then **Do the self-calibration whenever you think the balancer is not accurate. The 100g weight must be accurate.**

**\*\*It is necessary to install the normal car tire ruler head accessories and operate with car tires.\*\***

|        |                                                                                                                                                                                                    |       |                                                                                       |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------|---------------------------------------------------------------------------------------|
| Step 1 | Press  and hold, then press  | comes |  |
|--------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------|---------------------------------------------------------------------------------------|

|                           |                                                                                                                                                                |       |                                                                                     |
|---------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|-------|-------------------------------------------------------------------------------------|
| Step 2                    | Put down safe guard to start spin, after spin stop                                                                                                             | comes |  |
| Step 3                    | Open the safe guard and clip a 100 gram weight on the outside 12 o'clock position, put down safe guard to start spin, after spin stop                          | comes |  |
| Step 4                    | Open the safe guard and remove the 100g weight from outside then clip it on the inside 12 o'clock position, put down safe guard to start spin, after spin stop | comes |  |
| self-calibration finished |                                                                                                                                                                |       |                                                                                     |

## 6. Errors

Various abnormal conditions can arise during machined operation by the microprocessor, if comes the errors, must stop operation, find the reason and the solution according, if the error persists, consult the supplier.

| No. | Errors                                                                              | Reasons                                                                      | Solution                                                                                                                                                      |
|-----|-------------------------------------------------------------------------------------|------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1   |  | 1. No spin<br>2. Shaft spin                                                  | 1.If no spin, check or change power board<br>2.If spin, check or change position pick up board and computer board<br>3. Adjust position pick up board support |
| 2   |  | 1. No wheel or wheel not locked tightly<br>2. Position pick up board problem | 1. Lock tightly<br>2.Check or change position pick up board                                                                                                   |
| 3   |  | 1. No enough pressure in wheel<br>2. Wheel distortion                        | 1.Add proper pressure in wheel<br>2.Check wheel                                                                                                               |
| 4   |  | 1. Position pick up board problem<br>2. Computer board problem               | 1.Check or change position pick up board<br>2.Check or change computer board                                                                                  |
| 5   |  | 1. Micro switch problem<br>2. Computer board problem                         | 1.Check or change Micro switch<br>2.Check or change computer board                                                                                            |
| 6   |  | 1. Power board problem<br>2. Computer board problem                          | 1.Check or change power board<br>2.Check or change computer board                                                                                             |

|    |                                                                                   |                                                                                                      |                                                                                           |
|----|-----------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------|
| 7  |  | 1. Program lost<br>2. Computer board problem                                                         | 1. Self calibration<br>2. Check or change computer board                                  |
| 8  |  | 1. No add 100g weight during self calibration<br>2. Computer board problem<br>3. Power board problem | 1. Add 100g weight<br>2. Check or change computer board<br>3. Check or change power board |
| 9  |  | 1. Micro switch problem<br>2. Computer board problem                                                 | 1. Check or change micro switch<br>2. Check or change computer board                      |
| 10 |  | 1. Computer board problem<br>2. Power board problem                                                  | 1. Check or change computer board<br>2. Check or change Power board                       |
| 11 |  | 1. The machine is locked                                                                             | 1. Contact vendor unlock                                                                  |
| 12 |  | 1. Data protection                                                                                   | 1. Contact vendor unlock<br>2. Update data                                                |

## 7. Self- diagnoses

Press  and hold, then press  goest to self diagnoses, press  to next , press  escape

| Order | Display                                                                             | Function               | Function normal                                   |
|-------|-------------------------------------------------------------------------------------|------------------------|---------------------------------------------------|
| 1     |  | Display                | All lit up                                        |
| 2     |  | Position pick up board | Turn the shaft ,POS changes in 0-127              |
| 3     |  | Pressure sensor        | Use hand to press main shaft, 4X-4X 6X-6X changes |

## 8. Setting machine

### 8.1. Machine setting




★9.2 Press  and hold, then press  goes to set machine, press  and  to change , press  to next

| Order | Display | function | choice |
|-------|---------|----------|--------|
|-------|---------|----------|--------|

|   |  |                             |                                                                                                                                                                       |
|---|--|-----------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1 |  | Unbalance display threshold | 5/10/15                                                                                                                                                               |
| 2 |  | Sound                       | On/off                                                                                                                                                                |
| 3 |  | Light                       | 1-8                                                                                                                                                                   |
| 4 |  | Inch/mm                     | inch on/inch off                                                                                                                                                      |
| 5 |  | Tire weight(small tires)    | On/off                                                                                                                                                                |
| 6 |  | Laser switch                | OFF: 12 o'clock<br>ON: 6 o'clock                                                                                                                                      |
| 7 |  | Safe guard on               | Put down safe guard to start spin<br>Put down safe guard then press  to start spin |
| 8 |  | Unit of weight              | Gram/ Ounce                                                                                                                                                           |
| 9 |  | Tire operation type         | CAR: car Boot display [CAr]<br>Sco: Motorcycle Boot display [Sco]                                                                                                     |

## 9. Installation of motorcycle adaptor

★9.1 Use the motorcycle adaptor for wheel balancer we provide★

| Step 1                                                                                                                                          | Step 2                                                                                                                                  | Step 3                                                                                                                                                  |
|-------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------|
|  <p>(Fig.1)</p>                                              |  <p>(Fig.2)</p>                                     |  <p>(Fig.3)</p>                                                    |
| <ol style="list-style-type: none"> <li>1. Take off standard thread for car</li> <li>2. Replace with part No.9 in position A (Fig. 1)</li> </ol> | <ol style="list-style-type: none"> <li>1.Install part No.1 through No.9</li> <li>2.Lock and fix in position C and D (Fig. 2)</li> </ol> | <ol style="list-style-type: none"> <li>1. Take off the standard gauge head for car</li> <li>2. Replace with part No.2 in position B (Fig. 3)</li> </ol> |

★9.2 Press  and hold, then press  goes to set machine, press  and  to change, press  to next



| order | Display                                                                           | Function         | Display wheel type after turn on balancer                                          |
|-------|-----------------------------------------------------------------------------------|------------------|------------------------------------------------------------------------------------|
| 1     |  | Car wheel        |  |
| 2     |  | Motorcycle wheel |  |



★ “Display wheel type after turn on balancer” means after turn on machine, it comes signal to tell you it is a car mode or motorcycle mode.

## 10. OPT function

**Note: When unbalance value is too much, choose OPT, and operator must be experienced.**

Install wheel, input a b d value

|   |                                                                                                                                                  |                |                                                                                       |
|---|--------------------------------------------------------------------------------------------------------------------------------------------------|----------------|---------------------------------------------------------------------------------------|
| 1 | Press                                                          | comes >        |   |
| 2 | Put down safe guard and press                                 | comes >        |  |
| 3 | With the help of tire changer, change the rim and rubber 180 degree                                                                              | reference<br>> |   |
| 4 | Then put down safe guard and press                            | comes >        |  |
| 5 | Rotate wheel until four indicators lit up (two on both sides, the dark spot in the right side picture), mark the position C with chalk on rubber | reference<br>> |  |

|   |                                                                                                                                              |                |                                                                                     |
|---|----------------------------------------------------------------------------------------------------------------------------------------------|----------------|-------------------------------------------------------------------------------------|
| 6 | Rotate wheel until two indicators lit up (one on both sides, the dark spot in the right side picture), mark the position D with chalk on rim | reference<br>> |  |
| 7 | With the help of tire changer, change the rim and rubber to make C and D match                                                               | reference<br>> |   |
| 8 | Put down safe guard and press                               | comes >        | If unbalance is less than before, OPT succeed                                       |